


1. Circles:

Match the appropriate circle to the condyles of the femur and mark the centre point. Do the same with the condyles of the tibia. Connect the 2 points.



3	
6	
9	
12	
15	

2. Left Image: “Classical TTA template”

With the stifle in 135°, place the baseline on the tibial plateau and the “0” line against the cranial border of the patella. The required advancement (3 – 15) can be read at the level of the crista tibiae.

3. Right Image: “Common Tangent template”

With the stifle in 135°, hold the unmarked lines parallel to the line between the 2 points and place the “0” line against the cranial border of the patella. The required advancement (3 – 15) can be read at the level of the crista tibiae.

